

USE INSTRUCTIONS

1. Inflate the cushion using the air pump provided in the kit. Do not inflate the cushion fully like a balloon. The cushion works best when it is half filled or partially filled.



Less Air = More Comfort

2. For an Enhanced life of the Air Cushion, It is better not to expose the cushion to direct sunlight. It is a good practice to remove and take the cushion along with you, when you park your Motorcycle in hot sun.

USE INSTRUCTIONS

3. When you feel there is dust accumulation in the cushion cover / air mesh

- Wash the cover using water + mild detergent and dry in sunlight.
- Wash the cushion using plain water and allow it to dry indoor.

4. Avoid keeping the cushion near sharp and pointed objects.

5. You can do mild cornering, once you get used to the weight transfer by the cushion. For Race track like hard cornering, switch back to the stock seat.

To download the Installation Guide [click here](#)