

USE INSTRUCTIONS

1. Inflate/Deflate the cushion using the Mouth Inflation Valve – (Clockwise – Shut off / Anti-Clockwise – release). Do not inflate the cushion fully like a balloon. The cushion works best when it is half filled or partially filled.

Less Air = More Comfort

2. For an Enhanced life of the Air Cushion, It is better not to expose the cushion to direct sunlight. It is a good practice to uninstall and take the cushion along with you, when you park your Motorcycle in hot sun.

3. Check the Cushion and Cushion Cover Periodically for Dust/Sand accumulation. Follow the below steps to remove accumulated Dust/Sand.

- Wash the cover using water + mild detergent and dry in sunlight.
- Wash the cushion using plain running water (From/Under a Tap) and allow it to dry indoor.

* Punctures / Cracks / Tear arising out of Accumulated Dust/Sand are not covered under warranty.

4. Avoid sharp and pointed objects near the Cushion.

5. You can do mild cornering, once you get used to the weight transfer by the cushion. For Race track like hard cornering, switch back to the stock seat.